


REPAIR PARTS FOR 586 63 69-01 SPIKE AERATOR



EUROPEAN PART NUMBERS:

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	586 80 27-01	Shaft	6	4	586 80 77-01	Washer, .78" x 1.25" x .062"
2	10	586 80 19-01	Curved Spike Disk	7	2	504 06 63-01	Flange Bearing
3	20	531 00 76-30	Spike Disk Hub	8	2	531 00 27-38	Cotter Pin 5/32" x 1"
4	9	531 00 81-04	Spacer, .8" x 1" x 1.33"		1	41607	Owners Manual
5	2	506 62 65-01	Spacer, .76" 1" x .75"				

U.S.A. PART NUMBERS:

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	26369	Shaft	6	4	1540-31	Washer, .78" x 1.25" x .062"
2	10	25429	Curved Spike Disk	7	2	44798	Flange Bearing
3	20	45148	Spike Disk Hub	8	2	714-0121	Cotter Pin 5/32" x 1"
4	9	44494	Spacer, .8" x 1" x 1.33"		1	41607	Owners Manual
5	2	23368	Spacer, .76" 1" x .75"				